


CM5013-REAR




Product details are available at <https://www.fhgroupauto.com/product/ford-f150-xtl-lariat-raptor/>

PACKAGE INCLUDES




Warning


- Machine wash cold, delicate cycle. Air dry only.
- Avoid sharp objects to protect covers from being scratched/damaged.
- We suggest wearing protective eyewear and gloves during installation.




5 Place the Bottom 60 and 40 Side covers on the bench seat cushion and push the buckle straps to the center crevice of your car seat.




6 Attach the buckles of your Bottom 40 Side covers, according to the image above.




1 To start, remove the headrest by pushing the release button at the base of the headrest.




2 For the 60/40 split pull out the seat belt and place the Backrest 60 Side seat cover underneath it. Tuck in the sides of the seat cover into the crevices of the rear seat. Follow the contour of your car seat. Make sure you close the hook and loop strap near the seat belt holder.




7 Attach the buckles of your Bottom 60 Side covers, according to the image above.




8 Slip on the headrest cover and reattach the headrests. TIP: Starting from either side of the headrest and sliding the cover sideways will help you achieve a secure fit.



3 Push the rear hook-and-loop straps through the seat crevice. Attach the straps directly to the upholstery of the backseats.



4 For the Backrest 40 Side, push the rear hook-and-loop straps through the seat crevice. Lift up the bottom seat and attach the rear hook-and-loop straps underneath the bottom seat.



Enjoy!
10 Adjust accordingly, smooth out your custom-fit seat covers, and enjoy!